

## RECOMMENDED ADHESIVES GUIDE

	Laybond Bostik	F Ball & Co	Tremco	Uzin	Mapei
<b>isafe safety flooring</b>					
Horizontal Installation	Laybond HT Laybond Pressure Sensitive	F44, F48	SF105, SF108	KE2000S, KE66	Eco VS90, Eco 380
Horizontal Installation Extreme Conditions	Not Available	F81, F84	SF600	KR430	G19
Vertical Installation	Laybond PS - check with manufacturer	F66	SF108 - check with manufacturer	KE2000S - check with manufacturer	Aqua Contact
<b>Concept Woods &amp; Concept Decor</b>					
Horizontal Installation	Laybond HT Laybond Pressure Sensitive	F44, F48	SF105, SF108	KE2000S, KE66	Eco VS90, Eco 380
Horizontal Installation Extreme Conditions	Not Available	F81, F84	SF600	KR430	G19
Vertical Installation	Laybond PS - check with manufacturer	F66	SF108 - check with manufacturer	KE2000S - check with manufacturer	Aqua Contact
<b>Silento Design &amp; Silento Timber</b>					
Horizontal Installation	Laybond HT Laybond Pressure Sensitive	F44, F48	SF105, SF108	KE2000S, KE66	Eco VS90, Eco 380
Horizontal Installation Extreme Conditions	Not Available	F81, F84	SF600	KR430	G19
Vertical Installation	Laybond PS - check with manufacturer	F66	SF108 - check with manufacturer	KE2000S - check with manufacturer	Aqua Contact

IVC Group offers the following information for guidance only. The ultimate legal responsibility for the supply and performance of the adhesive remains the sole responsibility of the relevant adhesive manufacturer. IVC Group does not imply any equivalence between each of the different manufacturer's products, or that other products would not prove successful in application. When the list offers more than one adhesive, selection should be based upon suitability to the installation environment and the occupational use of the area. The application of the named manufacturer's adhesives must be in strict accordance with the relevant manufacturer's recommendations, which may include the application of a primer in certain situations, trowel notch size and specific installation methods. Site conditions, testing and installation must be in accordance with the current BS 8203: Installation of Resilient Floor Coverings or other relevant local standard. If in doubt seek further advice from the relevant manufacturer. Solvent based contact adhesives are not recommended for heterogeneous floorcoverings as they may stain the product.